

Bluetooth™ Headset - Micro

Getting Started Guide

1. Multifunction Button/Power Button

- Power On: Press and Hold for 2 seconds
- Power Off: Press and Hold for 3 seconds
- Pairing: Begin with the headset off. Press and hold for 5 seconds, the headset will speak "ready to pair" and the LED will flash blue and red while in discovery. When paired, the headset will speak "Device one connected"
- The two-way radio's push to talk button will need to be used instead of the multifunction button for transmitting.

2. LED Indicator

- Solid Red: Charging
- Solid Blue: Charging Complete
- Flashes Red and Blue: Pairing Mode
- Flashes red: Low Battery

3. EarTip

- Ergonomic design offers a more natural and secure fit in the ear.
- 3 Sizes included: Small, Medium, Large

4. Volume Up

- Click while receiving a transmission to increase volume. Will beep when highest volume level is reached.

5. Volume Down

- Click while receiving a transmission to decrease volume. Will beep when lowest volume level is reached.

6. Microphone

- Integrated DSP+CVC noise reduction microphone.

7. Ear Hook

- Optional and easy to attach. Hooks over ear to provide additional support.

8. Micro-USB Charging Port

- Connect the charging cable to the micro-USB charging port. The LED will light red while charging.



follow us on:



(952) 469-5400
 20809 Kensington Blvd., Lakeville, MN 55044
www.advancedwireless.com